$$\text{CONTAMINATION LEVEL (Bq/cm2)} = \frac{S - B}{E \times A \times T \times F}$$

Where:
S = Sample count rate (cpm or cps)
B = Background count rate (cpm or cps)
E = Detector efficiency (e.g. if 50% efficiency, E = 0.50)
A = Area wiped (100 cm^2) or detector area in cm^2
T = 60 sec/min if count rate in cpm
T = 1 if count rate in cps
F = 0.1 (e.g. 10%) is collection factor for area wiped (indirect monitoring or wipe test)

Net count rate (cpm or cps) = Sample count rate (cpm or cps) ±Background count rate (cpm or cps)
Detector efficiency = Net count rate (cpm) /Known activity (dpm)
1 microcurie (µCi) = 2.2 x 10^6 disintegrations per minute (dpm)
Detector efficiency = Net count rate (cps)/Known activity (dps)
1 Becquerel (Bq) = 1 disintegration per second (dps)
1 microcurie (µCi) = 37 kilobecquerel (kBq) = 37000 becquerel (Bq)

Non-fixed contamination in all areas, rooms or enclosures where unsealed nuclear substances are used or stored does not exceed 3 Bq/cm^2.

Problem :
You have taken a swipe for unsealed H-3 and S-35 contamination in your designated radiation room. The liquid scintillation counter print out shows a sample count rate of 940 cpm for the swipe of the fume hood in 100 cm^2. The